



# 72643B - INSTRUCTION SHEET

## GENERAL INSTALLATION INSTRUCTIONS:

1. Disconnect the electricity at the circuit breaker or the fuse box. Disconnecting power using the wall switch is not sufficient to prevent electrical shock.
2. Cut a 5-1/8" hole for the 6" fixture.
3. Open the junction box on top of the housing.
4. Locate ROMEX CABLE (power source) in the ceiling and pull through the ceiling hole. Identify the size of the cable.
5. Using a screwdriver, remove the 1/2 or 3/4 round knockout on the side of the junction box.
6. Remove 3" of sheathing from the ROMEX CABLE.
7. Using the quick connectors in the junction box insert the wires inside of the ROMEX CABLE AS FOLLOWS:  
WHITE WIRE IN ROMEX CABLE TO WHITE WIRE QUICK CONNECTOR (NEUTRAL)  
BLACK WIRE IN ROMEX CABLE TO BLACK WIRE IN QUICK CONNECTOR (HOT/LIVE)  
GREEN / BARE WIRE IN ROMEX CABLE TO GREEN WIRE QUICK CONNECTOR (GROUND)
8. Carefully stuff all wires/connectors back into the junction box.
9. Snap/replace the cover on top of the junction box.
10. Insert the recessed lighting fixture into the ceiling with the spring clip in the up position.
11. The recommended installed distance between fixtures is 24" or 36".

Warning-risk of fire or electric shock. Installation of this fixture requires a person familiar with the construction and operation of the luminaire's electrical system and the hazard involved. If not qualified, do not attempt installation. Contact a qualified electrician.

Warning-to prevent wiring damage or abrasion , do not expose wiring to edges of sheet metal or other sharp objects.

