

Heavy Duty Solenoid Voltage/Continuity Tester



- ▶ Test Voltage from 120V to 600V AC/DC
- ▶ Non-Contact Voltage Sensor from 90V to 1000V
- ▶ Test Continuity & Polarity
- ▶ Case serves as prod holder for one-hand operation
- ▶ Self-storing prods
- ▶ Solenoid Sensing indicated by LEDs & Vibration
- ▶ Ergonomic Soft PVC housing for comfort grip
- ▶ LED Spotlight Illuminates Work Area
- ▶ Battery not Included (AAA x 1)

Cat. No.	Inner Box Qty	Case Qty
59100	5	60

Battery/Bulb/Fuse/Continuity Tester



- ▶ Multi-purpose Battery, Bulb, Fuse, & Continuity tester
- ▶ Determines if Battery, Bulb or Fuse is still good
- ▶ Audible continuity tester via test probes supplied
- ▶ Reading shows up on clear scale
- ▶ Operated by one 9V 6F22 battery (not supplied)
- ▶ Automatically turns power on and off
- ▶ Dimensions: 5.7" x 2.6" x 1.3"
- ▶ Weight: 5oz.

Cat. No.	Inner Box Qty	Case Qty
59002	10	60

Motor and Phase Rotation Indicator



- ▶ Detects the rotary field of three-phase systems & determines the motor rotation direction
- ▶ Determines the Motor Connection
- ▶ Stand alone direction indicator
- ▶ Hand held, battery-operated
- ▶ Wireless

Cat. No.	Case Qty
57088	20

Light Meter



- ▶ Easy-to-use, Pocket Size & Light Weight
- ▶ 3-1/2 Digit LCD Display with Low Battery Indication
- ▶ Resolution To 0.1 Lux Measurement
- ▶ Measuring Range 200, 2000, 20000, 50000 Lux
- ▶ 20000 Lux: Reading x 10, 50000 Lux: READING x 100
- ▶ Accuracy: $\pm 5\%$ Rdg ± 10 Digits (<10,000 Lux)
- ▶ Accuracy: $\pm 10\%$ Rdg ± 10 Digits (>10,000 Lux)
- ▶ Calibrated to Standard Incandescent Lamp 2856K
- ▶ Includes One 12 Volt Battery
- ▶ Photo Detector Dimensions: 4.5" X 2.4" X 1.1"
- ▶ Dimensions: 4.5" X 2.5" X 1.1"
- ▶ Weight: 5.6 Oz

Measures both footcandle & Lux
1 footcandle = 10.76 lux

Cat. No.	Inner Box Qty	Case Qty
59150	10	40