



**Easy to do
business with...**

98033, 98034, 98036, 98038 Installation Information

1. Remove cable insulation 1-3/8" from end of conductor. (Insulation strip length imprinted on bottom of connector)
2. Wire brush bare conductor, apply oxide inhibitor.
3. Remove conductor sleeve from connector.
4. Select and cutoff the correct step end at tip of arrow on the sleeve. Make sure to cut sleeve straight across the end of step. Discard sleeve for 500 and 600 MCM.
5. Dielectric silicone grease may be applied to the cable insulation, slide on the conductor sleeve.
6. Remove set screw access plug and loosen set screw to allow cable insertion.
7. Insert Conductor and sleeve into the cable outlet until conductor hits the back of the connector and tighten set screw to the recommended torque. (Table 1)
Conductor sleeve should be installed to original depth.
8. Replace set screw access plug.
9. When using conductor sleeve (400 MCM and smaller) slide the sleeve completely into the cable outlet until the sleeve end contacts the end of the cable outlet.

Table 1	
Conductor Range	Inch-Pounds
#12 - #6	135
#4 - 3/0	210
4/0 - 350	360
400 - 600	500

